

ISABELLE coup

Design M. Machek

fine dining

Isabelle

A new way of porcelain without rim. ISABELLE COUP lives out ease and sophistication of the contemporary fine dining culture. The rimless and free flowing design will turn dining into a remarkable experience. Whether you prefer pure white, matt glazing or nice decorations – the stage is yours.

Porzellan ohne Fahne neu definiert. ISABELLE COUPE zelebriert die Leichtigkeit und Raffinesse der zeitgenössischen Tafelkultur. Randlose und weich fließende Formen machen das Essen zum Erlebnis. Ganz egal, ob Sie lieber pures Weiss, matt glasiert oder fein dekoriert bevorzugen – Die Bühne gehört Ihnen.



Isabelle



ISC2130
 plate flat / Teller flach
 30 cm



ISC2127
 plate flat / Teller flach
 27 cm



ISC2116
 plate flat / Teller flach
 16 cm



ISC2121
 plate flat / Teller flach
 21 cm



ISC2124
 plate flat / Teller flach
 24 cm



DIV2134
 plate flat / Teller flach
 34 cm



ISC1929
 plate deep / Teller tief
 29 cm



ISC1917
 bowl / Schale
 17 cm



ISC1923
 plate deep / Teller tief
 23 cm



ISC1913
 bowl / Schale
 13 cm



ISC1926
 pasta plate / Pastateller
 26 cm

ISABELLE coup



Isabelle



ISC3020
oval plate / Platte oval
20 cm



ISC3028
oval plate / Platte oval
28 cm



ISC3032
oval plate / Platte oval
32 cm



ISC1518
deep oval plate / Platte oval tief
18 cm



ISC1526
deep oval plate / Platte oval tief
26 cm



ISC1530
deep oval plate / Platte oval tief
30 cm



ISB9412
votive / Kerzenhalter



ISB5000 / ISB5030
salt shaker & pepper shaker
Salzstreuer & Pfefferstreuer



ISB9418
oil & vinegar
Karaffe Öl, Essig
18 cl



ISL2119
plate flat / Teller flach
19 cm



ISL2123
plate flat / Teller flach
23 cm



ISL2127
plate flat / Teller flach
27 cm



ISC1415
bowl / Schüssel
15 cm



ISC0309
bowl / Schüssel
7 cm



DIV1929
pasta plate / Pastateller
29 cm




ISC1413
bowl / Schüssel
13 cm



ISC1416
bowl / Schüssel
16 cm

ISABELLE coup





Isabelle

- 

ISC1816
saucer / Untertasse
16 cm
- 

ISC1816
saucer / Untertasse
16 cm
- 

ISC1816
saucer / Untertasse
16 cm
- 

ISC1816
saucer / Untertasse
16 cm
- 

ISC1716
saucer / Untertasse
16 cm
- 

ISC4145
tea pot / Teekanne
45 cl
- 

ISC0835
tea cup / Tasse
35 cl
- 

ISC1716
saucer / Untertasse
16 cm
- 

ISC4141
combo set
- 

ISC0309
jasmin tea / Tasse
9 cl
- 

ISC1711
saucer / Untertasse
11 cm
- 

ISB0622
coffee cup / Tasse
22 cl
- 

ISB0808
espresso cup / Tasse
8 cl
- 

ISB1711
saucer / Untertasse
11 cm
- 

ISB3608
creamer / Giesser
8 cl
- 

ISB4260
lid / Deckel
- 

ISB4160
pot / Kanne
60 cl
- 

ISB4212
lid / Deckel
- 

ISB4012
pot / Kanne
1,2 l