

Points X882 I
Points



ISC2130
plate flat / Teller flach
30 cm



ISC2127
plate flat / Teller flach
27 cm



ISC2124
plate flat / Teller flach
24 cm



ISC2121
plate flat / Teller flach
21 cm



ISC2116
plate flat / Teller flach
16 cm



ISC0835
tea cup / Tasse
35 cl



ISC1716
saucer / Untertasse
16 cm

ISB0815
coffee cup / Tasse
15 cl




ISB1714
saucer / Untertasse
14 cm

ISB0808
espresso cup / tasse
8 cl



ISB1711
saucer / Untertasse
11 cm



DIV1929
pasta plate / Pastateller
29 cm



ISC1923
plate deep / Teller tief
23 cm



ISC1926
pasta plate / Pastateller
26 cm



ISC1413
bowl / Schale
13 cm



ISC1716
saucer / Untertasse
16 cm



ISC1416
bowl / Schale
16 cm



ISB2131
plate flat / Teller flach
31 cm



ISB2128
plate flat / Teller flach
28 cm



ISB2126
plate flat / Teller flach
26 cm



ISB2123
plate flat / Teller flach
23 cm



ISB2120
plate flat / Teller flach
20 cm

POINTS



Points
white
X8858



ISC1917
plate deep / Teller tief
17 cm



ISC1923
plate deep / Teller tief
23 cm



ISC1926
pasta plate / Pastateller
26 cm



ISC2130
plate flat / Teller flach
30 cm



ISC2127
plate flat / Teller flach
27 cm



ISC2124
plate flat / Teller flach
24 cm



ISC2121
plate flat / Teller flach
21 cm



ISC2116
plate flat / Teller flach
16 cm

POINTS