




X8753

# Vintage



ISC2130 plate flat / Teller flach 30 cm  
 ISC2127 plate flat / Teller flach 27 cm  
 ISC2124 plate flat / Teller flach 24 cm  
 ISC2121 plate flat / Teller flach 21 cm  
 ISC2116 plate flat / Teller flach 16 cm



CHC2130 plate flat / Teller flach 30 cm  
 CHC2127 plate flat / Teller flach 27 cm  
 CHC2124 plate flat / Teller flach 24 cm  
 CHC2121 plate flat / Teller flach 21 cm  
 CHC2116 plate flat / Teller flach 16 cm



CHC3032 oval plate / Platte oval 32 cm  
 ISC3032 oval plate / Platte oval 32 cm  
 ISC3028 oval plate / Platte oval 28 cm  
 CHC3028 oval plate / Platte oval 28 cm



CHC3020 oval plate / Platte oval 20 cm  
 ISC3020 oval plate / Platte oval 20 cm



CHC1926 pasta plate / Pastateller 26 cm  
 ISB9418 oil & vinegar Karaffe Öl, Essig 18cl  
 CHC1416 bowl / Schale 16 cm  
 CHC1413 bowl / Schale 13 cm



CHC4260 lid / Deckel  
 CHC0825 tea cup / Tasse 15 cl  
 CHC0815 coffee cup / Tasse 15 cl  
 ISC1816 saucer / Untertasse 16 cm  
 CHC4160 pot / Kanne 60 cl

VINTAGE

VINTAGE



Points X882 I  
*Points*



ISC2130  
plate flat / Teller flach  
30 cm



ISC2127  
plate flat / Teller flach  
27 cm



ISC2124  
plate flat / Teller flach  
24 cm



ISC2121  
plate flat / Teller flach  
21 cm



ISC2116  
plate flat / Teller flach  
16 cm



DIV1929  
pasta plate / Pastateller  
29 cm




ISC0835  
tea cup / Tasse  
35 cl




ISB0815  
coffee cup / Tasse  
15 cl



ISB0808  
espresso cup / tasse  
8 cl



ISC1716  
saucer / Untertasse  
16 cm



ISB1714  
saucer / Untertasse  
14 cm



ISB1711  
saucer / Untertasse  
11 cm



ISC1923  
plate deep / Teller tief  
23 cm



ISC1926  
pasta plate / Pastateller  
26 cm



ISC1716  
saucer / Untertasse  
16 cm



ISC1416  
bowl / Schale  
16 cm



ISC1413  
bowl / Schale  
13 cm



ISB2131  
plate flat / Teller flach  
31 cm



ISB2128  
plate flat / Teller flach  
28 cm



ISB2126  
plate flat / Teller flach  
26 cm



ISB2123  
plate flat / Teller flach  
23 cm



ISB2120  
plate flat / Teller flach  
20 cm

POINTS



*Points*  
*white*  
X8858



ISC1917  
plate deep / Teller tief  
17 cm



ISC1923  
plate deep / Teller tief  
23 cm



ISC1926  
pasta plate / Pastateller  
26 cm



ISC2130  
plate flat / Teller flach  
30 cm



ISC2127  
plate flat / Teller flach  
27 cm



ISC2124  
plate flat / Teller flach  
24 cm



ISC2121  
plate flat / Teller flach  
21 cm



ISC2116  
plate flat / Teller flach  
16 cm

POINTS